

Danfoss Icon™ Master Controller 24V



1. 1.1

1.2

1.3

1.4

1.5

2. 2.1

2.2

2.3

2.4

3. 3.1

3.2

4.1

4.2

5.

6.

7.

8.

9.

10.

11.

12.

13.

14.

15.

16.

10. Cable pin out

1	2	3
---	---	---

1. GND
2. COM A
3. COM B

17. Cable/wiring Danfoss Icon™ Master Controller 24V

24V

2 x 2 x Ø 0,6 PDS cable (UTP or STP)	☺
H03VV-F 0,50 mm ² , flexible	☺
H03VV-F 0,75 mm ² , flexible	☺
3 x 1,0 mm ² , solid core	☺
3 x 1,5 mm ² , solid core	☺
5 x 1,5 mm ²	☹
> 1,5 mm ²	☹
< 24 AWG	☹

18.1

18.2

18.3